

1/2



# **Multi-Cleaner DC-5000**

# Powerful Cleaner

Aerosol 500 g/can, 20cans/Box



### Features

#### Cleanliness

Excellent cleaning power harmonized with evaporation can remove oil, grease, dust or flux on the surface of object easily.

#### Stability

Having special features of electro-induction, incombustibility, non-explosiveness and low-toxic, it is used safely while operating.

#### Uses

Cleaning of oil, grease and dust of machinery

Cleaning of motor, generator, engine etc.

Cleaning of spark plug, circuit-breaker, valve etc.

Cleaning and degreasing of crank case, break pad, cylinder, spring etc.

High Voltage Cables Cleaning

#### How to use

Cleansing by Spraying: Spray about 20-30 cm away from the object.

**Dipping Method:** Grease or oil stain can be dissolved and cleaned when the object dips into the multi-cleaner, DC-5000.

**Brushing Method:** When you clean severely polluted materials within a short time, you have to dip it in the fluid of multi-cleaner and brush it for effective cleaning. You have to choose a brush for cleaning of the nonferrous metals or plastic products carefully.

**Spray Method:** Excellent cleansing effect against non-soluble contaminants such as dust by using solubility and spray pressure of Multi-Cleaner DC-5000.

Ultra-Sonic Method: Excellent cleaning effect using vibration of fluid of ultra-sonic cleaner.



204, Chucus Sandam 1-gl, Pasingssong-oup, Pycongram III, Nipconggi-do 451-805 NCREA TEL 1 82-31-801-591-8 FAX 1 82-31-801-6441, 668-6441 Home Page 1 www.habokem.com





## Cautions

Test is required before applying.

This should be used only for its intended purpose.

Ventilation is necessary when using the cleaner.

Do not inhale it for a long period of time.

Avoid long contact with skin.

Do not use it other than its purpose.

Make proper ventilation during the application. In addition, do not breathe into the body for a long time. Avoid touching the skin for a long time. Keep out of the reach of children.

Using high-pressure gas is dangerous, so pay the attention to the following notes.

- 1. Do not keep it in a 40 °C or higher place.
- 2. Do not dispose it on fire.
- 3. After use, make sure to dispose it with no remaining gas.
- 4. Make sure not to keep it in an enclosed place.

\* This information can be amended without any notice according to new knowledge and test result. If there are any questions, please contact us or the store where you purchased it.



